

BBU / LDCO800 Operation & Behavior	
LDCO800 with BBU Operation	Features
# Door Cycles: Immediately after power outage	50 minimum
# Door Cycles: After 24 hour of stand-by without operation	10 minimum
Beam Operation:	Turns on when door traveling in down direction, turns off 5 minutes after door is fully closed
Light Function In Battery Operation: (When Light Button is Pressed)	Beams turn on for 5 minutes
Courtesy Light Operation:	Light does not turn on
Battery Self-Check:	BBU regularly performs a self-check routine. If self-check detects that the batteries are no longer serviceable, 3 beeps will sound every minute, prompting for service call; Terminating connector can be used to stop beeps.
LDCO800 initial installation	Features
Beam Operation During Initial Setup:	Beams remain on until travel limit and force adjustments. Turns off 5 minutes after adjustments
Beam Normal Operation	Features
Beam Normal Operation:	Turns on when door traveling in down direction, turns off 5 minutes after door fully closes
Beam Idle Operation:	Off
If Light Button is Pressed:	Beams turn on for five minutes